

Manifold Installation:

The new manifold comes with only 1 pulse hole.

The manifold will need to be mounted with the pulse hole on the bottom and the Teflon gaskets will need to be installed the same way as well.

Only use the supplied Teflon gaskets, no other gaskets allowed.

The manifolds are threaded 5mm for the mounting of the carburetor.

The carburetor can be mounted using bolts or studs, however please make sure that the method used and installation is not going to create an air leak.

After initially running the new manifold it may be necessary to recheck the bolts / nuts for tightness.